

Flügger H2O are used for surface treatment in bathrooms and similar rooms. The products are used subject to applicable legislation and notices regarding requirements for substrate, performance and water and moisture density.

Product properties

Primer and intermediate treatment for wet room. Recommended for surfaces that are exposed to particularly high functional requirements, where changing moisture and water conditions occur. Included in the Flügger wet room system in combination with Filler PRO H2O, Adhesive H2O, H2O Sealer Pro, Glass woven Wetroom and Dekso 20 H2O.

- **Primer and intermediate treatment**
- **Included in the Flügger wet room system**
- **Blue toned**

Product use

Bathrooms, toilets and similar wet rooms.

Used cf. applicable legislation and decrees on requirements for substrates, performance, water and vapor tightness.

Substrate

Must be clean, dry, firm and suitable for surface treatment.

Treatment

Remove loose material and paint by cleaning and sanding.

Remove dirt, grime, grease and chalking materials by cleaning with Fluren 37.

Remove lime and soap residue using Fluren 33.

Sand hard, slippery surfaces flat.

Cracks, holes and unevenness are filled with a suitable joint/filler.

If necessary, absorbent and porous substrates can be primed with Sealer.

Apply as a base treatment before setting up the wall covering.

After setting up the wall covering, apply Dekso H2O Primer before finishing treatment with Dekso 20 H2O.

Application

Brush or roller.

Decide your choice of tool/utensil depending on the finish.

Apply wet on wet and finish by brushing/rolling in the same direction.

Cold/heat can affect the viscosity of the material.

Condensation during drying/curing must not occur.

Cold and increased humidity extends drying time, full curing and recoat interval.

Increased temperature and low atmospheric humidity reduce drying time and full curing.

Always perform a test treatment for a check and acceptance of adhesion and result.

Expected result

Transparent blue-toned surface for further treatment.

Finish treatment with wall covering and/or Flügger Dekso 20 H2O.

Coat the surface with care and avoid direct contact with water before the paint is fully cured.

Environmental information

Clean off the paint from tools and wash them with water. Bring remains of fluent paint to the local recycling centre. Minimize your paint waste by pre-estimating how much paint you need. Keep the leftover paint for future use so you can effectively reduce the environmental impact.

Storage: Cool, frost free and tightly closed

Technical Data

Density (kgs/l)	1.03
Solids Weight %	39
Solids Vol. %	37
Nominal spreading rate (m ² /ltr.)	6
Min. working temp. during application and drying/curing	Min. +10°C
Humidity	Max. humidity 80 % RH.
Drying time at 20° C, 60 % RH (Hours)	1
Recoatable at 20° C, 60 % RH (Hours)	2
Fully cured at 20° C, 60 % RH (Days)	28
Emission acc. to ISO 16000-9:2011 (< µg/m ² h after 28 days)	10
Dilution	Water
Cleaning of Tools etc.	Water

Current TDS Version

January 2023