

Adhesive powder

Product properties

Transparent, reinforced adhesive. For hanging sawdust wallpaper, paper wallpaper and non-woven wallpaper. The adhesive is applied to the back of the wallpaper. For hanging non-woven wallpapers where the adhesive is applied on the wall.

- **Wallpaper adhesive, non-woven**
- **Mix with water**
- **Also for pre-gluing**



Product use

Indoors in a dry room for hanging sawdust wallpaper, paper wallpaper and non-woven wallpaper.

On concrete, lightweight concrete, plaster, gypsum board, fibreglass, wood-fibre boards, veneer sheets, chipboard and sandblasted substrates.

Substrate

Must be clean, dry, firm and suitable for substrate treatment.

Treatment

Remove loose material and paint by cleaning and sanding.

Remove dirt, grime, grease and chalking materials by cleaning.

Water-soluble discolouration, nicotine and soot are cleaned and treated with blocking primer.

Hard, smooth substrates should be sanded to a matt finish and painted with primer.

Cracks, unevenness and holes must be filled.

Paint absorbent and porous substrates with primer.

Untreated, painted and wallpapered substrates should be primed.

Application

Brush or roller.

Adjust layer thickness to substrate and wall covering.

Mixing: Slowly pour 1 bag of powder while stirring in a bucket of cold water to a uniform consistency.

The amount depends on the area of application.

For setting up wallpaper 3-4 l/bag. For priming 8 l/bag.

Leave to rest for 3-5 minutes and stir again and let the adhesive rest for a minimum of 15 min. before use.

When hanging up the sawdust and paper wallpaper, apply the adhesive to the back of the wallpaper.

Let the wallpaper draw approx. 10 min. before hanging.

When hanging up non-woven wallpaper, the adhesive can be applied to the back of the wallpaper or directly to the wall.

Allow the adhesive to dry briefly before setting up.

Differences in layer thickness or uneven structure can result in a non-uniform substrate.

Insufficient layer thickness results in the risk of blistering and inadequate adhesion.

Excess layer thickness results in the risk of cracking.

Adhesive applied to the front of the wallpaper may cause visible stains.

Cold/heat can affect the viscosity of the material.

Condensation during drying/curing must not occur.

Cold and increased atmospheric humidity extends drying time and full curing.

Increased temperature and low atmospheric humidity reduce drying time and full curing.

Always perform a test treatment for a check and acceptance of adhesion and result.

Expected result

Uniform and well fastened to substrate.

Does not prevent penetration of knots and water-soluble dyes, water stains and nicotine.

Exercise care in loading the substrate until the adhesive is fully cured.

Please note!

Ensure good ventilation during and after hanging.

Environmental information

Remove as much paint as possible from tools before cleaning.

Bring remains of fluent paint to the local recycling centre.

Minimize your paint waste by pre-estimating how much paint you need.

Keep the leftover paint for future use so you can effectively reduce the environmental impact.

Storage: Cool, frost free and tightly closed

Technical Data

Nominal spreading rate (m²/ltr.)

5

Min. working temp. during application and drying/curing

Min. +15°C

Humidity

Max. humidity 80 % RH.

Dilution

Water

Cleaning of Tools etc.

Water

Current TDS Version

March 2024

Replaces TDS Version

August 2022